Carlota freestyle. 9100 User Guide



Contents

(EQUIPMENT	·
	External compo	nents
	Internal and bac	kroom components

OPERATIONS

Ways to pour a drink6
Pouring with ADA interface7
Mobile pour
Filling the ice bin9
Accessing the ingredient summary and crew dashboard
Understanding the ingredient summary
Understanding the crew dashboard
Cartridge prime procedure13
Manager lock mode
Calorie counter display15
Using & pairing with myCoke mobile app16



For crew training videos, visit crewconnect.coca-cola.com

This guide provides general tips and proper maintenance procedures for your Coca-Cola Freestyle® 9100 dispenser.

PRODUCT REPLACEMENT

Replacing cartridges18	
Replacing HFCS sweetener 20	
Replacing NNS sweetener21	

MAINTENANCE


Helpful cleaning tips	22
Cleaning nozzle, injector ring, and ice chute	23
Cleaning ice bin	24
Cleaning drain and cup rest	25
Cleaning the NNS compartment and connector	26
Cleaning exterior surfaces	27
Cartridge maintenance	28

RESOURCES

Small parts	9
Crew Connect 3	0

External components

- A Ice bin lid*
- B Touch screen
- **C** Touch to pour button
- Nozzle & injector ring
- E Ice lever
- F Cup rest
- G RFID reader
- H ADA interface
- Lower door
- J Door handle
- K Ice lid hook*
- L Lower door manual entry button




* Not applicable with top-mounted ice maker

COCA-COLA FREESTYLE® 9100 | EQUIPMENT

Internal and backroom components

A Power switch B Double cartridge slots C Single cartridge slots D Non-nutritive sweetener (NNS) 2235



Ways to pour a drink

Limitless options with three ways to pour.

User interface key

- Primary Brands When a primary brand is selected.
- Empty or Unavailable Brands

Grayed-out brand buttons indicate the brand is out and unavailable.

- Sort Drinks Sort by drink preference.
- **Brand Flavors** Flavors available for the selected primary brand. The selected flavor is indicated by expanded size.
- **Calorie Counter Display** Shows the drink calorie amount based on size.

(1) Add ice Place your cup under the ice chute and press lever to dispense ice.

(2) Select primary brand

Choose primary beverage brand by pressing the desired Brand Button.



$(\mathbf{3})$ Select brand flavor Select brand flavor by pressing Flavor Button. Then press the Touch to Pour Button to dispense your beverage.




COCA-COLA FREESTYLE® 9100 | OPERATIONS

Pouring with ADA interface

Using the ADA interface

The ADA interface allows people with reach challenges (such as those in wheelchairs) to use the Coca-Cola Freestyle[®] dispenser without having to reach the touch screen.




operational obligations.

3	Use the arrows to navigate to your favorite beverage.	$(\square$
4	Press the hand icon to pour.	(R

Assisting guests with pouring drinks

If someone looks like they might need assistance (e.g., he/she is visually impaired or height/reach challenged), tell your quest that you have the Coca-Cola Freestyle dispenser and that you would be happy to assist with their beverage choice.


It is up to you to determine whether the above satisfies your legal and



Mobile Pour

How to use Mobile Pour

Mobile Pour allows customers to use their mobile phones to dispense their favorite Coca-Cola Freestyle beverages without downloading a special app or membership.



Place cup in dispenser and push lever for ice.



Scan QR code using smartphone camera. Be sure to hold your phone in front of the QR code.

NOTE: Do not hold it lower than the dispenser screen.



Select desired brand and drink.



Press "hold to pour" button and release it to stop. Keep button pressed until cup is full. COCA-COLA FREESTYLE® 9100 | OPERATIONS

Filling the ice bin

How to check and fill the ice bin

Maintaining the proper ice level is critical to ensuring guests receive a quality beverage.

Check to ensure ice is at


least ¹/₃ full at all times. For a

top-mount ice maker, follow


established procedures for


checking ice level. Fill the ice

bin by following these steps.




Fill a clean bucket with ice and open ice bin lid.






Dump the ice in the ice bin and fill until full (approximately 2" from the top). Do NOT overfill.



Close ice bin lid.

Accessing the Ingredient Summary and Crew Dashboard





Pour Screen & secret handshake

On the all brands consumer screen, place your index finger on the lower left of the screen between the water icon and the red all drinks button. Hold for 5-6 seconds to launch the ingredient summary.

The Ingredient Summary screen can also be accessed by using the RIFD scanner and scanning in the tag on a cartridge to open the lower door.

Ingredient Summary

From the Ingredient Summary screen - press the Details Button 📖 to open the Crew Dashboard.

$(\mathbf{3})$ Return to Pour Screen

A1 Kinta tinia		A3 time ken tupe		AS tons		AT 17 Mart Solar A		AD In: Pappar		All Barip	
21+ slages SATS		21+ days 45%		21+ days 6.0%		21+ days SIN SIN May by McMass		20- days 1		20+ days 215 215	
31 Line	12 Ingr Asiation AA	33 Respective at		35 Weisensteine		27 Natio Natio		13 84	12 Viterinaater	31 Northe Part Jr	10
16 days Sectors 3.2 N	21+ days 	21+ slaps 28%		21+ days terminety RON		21+ days Interesting 2015		20× slavja 1414-141 345	6 days terraining 2%	02 days Television	21 1
203 Brape	216 Mushavy	115 Raightry	276 Pesarata	117 Anti-Rosterry Pomepunate	218 Varite		220 Marga	321 Lamon	302 many	325 Falta	
21+ sleps standing 60%	20 days statistic 20%	21+ stays SOL	20+ days 24%	34%	21 stays schemes 23%		21+ sleps 42%	21+ days second p	21+ slags second 26%	20+ days seturing 27%	2 0 12
PP16	2005	water .	Sparking Water	***	that spears	tark speece					
•	•	•	•	•	•	•					

Crew Dashboard

Return to the pour screen, press the Exit Button I at the top right, and continue to follow the on-screen instructions.



COCA-COLA FREESTYLE® 9100 | OPERATIONS

Understanding the Ingredient Summary

changi Ingred

Actio

Low

S12 Vitaminw

3 hours

5%

A High Priority

Items requiring immediate attention to resume function. Reach out to the support team for assistance at 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653).

B Action Required

Items requiring action:

- Change the cartridge if the ingredient is shown in a red sold-out status.
- Select the Prime All Button to prime the lines for the orange prime required gauges.

C Low Levels

Highlights ingredients (less than 20%) that are running low and will need to be replaced soon.

D Details

Use to access the Crew Dashboard.

Back to Pour Screen (Close)

To return to the Pour Screen, select Close 🛞 or the Back to Pour Screen Button.

Remember, the product door must be closed to get back to pour screen.

If the Ingredient Summary screen or crew dashboard has not been accessed within the past 24 hours, a cleaning instructions screen will appear (right).

			Ingred	ient S	umma	ary	Details	? Help	Close
Priorit	y								
ution AA e before g to new nt									
n Requ	uired								4/4
ro Sugar quired	A7 CF Diet Coke A Prime required	S1 Mello Yello Sold Out							
Levels									1/1
ator					(E)			
			Prime All		Back to Po	ur Screen			

Understanding the crew dashboard

When crew members require a complete view of the status of all inaredients, the crew dashboard screen can be accessed.

A Bold Alerts

Review items requiring attention to resume ingredient function, such as sold out, prime, or purge.

Contact the support team if vou need assistance at 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653).

8	Fuel	Gauges

Color-coded gauges displaying the remaining product percentage and Enjoy By Date of each cartridge improve cartridge change-out management for crew members and reduce product waste.

The percentage remaining and time before changing the ingredient cartridge may vary significantly. For example, a flavor cartridge with 6% may have several days remaining, while a heavily used ingredient cartridge, like Coca-Cola, may last only a few hours with 6%.


S12 Dashboard Fruit Punch, NA A11 Bargs A1 Coca-Cola A3 Coke Zero Sugar A5 Diet Coke A7 CF Diet Coke A 21+ days 21+ days 21+ days 21+ days 21+ days 21+ days 66% Chicy By 08/27/2* 45% 58% 69% 5 davs Enjoy By 08/12/23 Enjoy By 08/19/23 Enjoy By 08/05/23 ____ remaining S1 Lime S2 Ingr Solution S7 Mello Yello S2 Vitaminwater S12 S2 Fruit Punch, NA Fuze Tea C2 Cherry 89% A 5 days 16 days 21+ days 21+ days 4 days remaining 21+ days remaining 21+ days 21+ days 32% Enjoy By 12/ 39% 36% 7% 77% 89% 37% Enjoy By 04/15/22 -----Enjoy By MM/DD/YY S13 Grape S14 Strawberry S21 Lemon S22 Vanilla, NA S24 Fruit Punch S22 (A 21+ days 21+ days 21 days 21+ days 21+ days c1 hour emaining 21+ days 21+ days remaining Vanilla, NA 49% 35% 34% 23% 42% 24% _ HFCS Shelf Agitator <1 hour remaining 0% C Time Remaining Eniov By MM/DD/YY

A time remaining feature provides an accurate reading when each cartridge will likely run out. This new feature is calculated using the dispenser's consumption activity and daypart data to deliver a dynamic and precise reading throughout the day.

COCA-COLA FREESTYLE® 9100 | OPERATIONS

Cartridge prime procedure

Priming an ingredient cartridge simply removes any trapped air in the line and ensures guests receive a consistent, quality beverage.





(1) Confirm the cartridge has been inserted into the correct slot and press the Prime All Button at the

						•0 (à <u>8</u>	9 5-11
	All Balt from		12 17 mar 1 mar 4		AD Ni Pappar		Art Barta	
	211 days 64%		207 days 53%		217 daps		20 days 205	
	SS Mid Lamonada		27 Rodin Yara			12 Vitalitinaatar	li Northe Part of	No. of the state o
	21+ days 3-0%		207 days 34%		211 days 36%	4 days 2%	10 stays	21+ staps 32%
-	10 Anti-Roadiany Ponagwate	218 Varieta		120 Marga	101 setter	ing meny	A20 Reffix	Red mon
	345	21 days		217 days 42%	201 days	217 days 24%	217 days 27%	211 daps 2015
-	•	warapunr	•					
	(Prim	e All					
<u> </u>								
	Pi	rim	e A	ALL				

(2) When priming is complete, press $Exit \otimes$ in the top right of the screen. Follow the prompts on the pop-up to continue to the main screen.

2
Navigate to Consumer Interface
Are you sure you want to navigate to the consumer interface now?
Cantal

NOTE: Only press the Prime All Button ONCE! Pressing it more than once will needlessly repeat the prime process.

REMINDER: The prime process lasts approximately 5-10 seconds depending on cartridge size, i.e., single or double. The process should NEVER be interrupted.

Manager lock mode

Manager lock mode

Managers can lock the Coca-Cola Freestyle dispenser to prevent drinks from being poured without having to manually power off the unit.



Access the crew dashboard. Then tap the 'Lock' icon in the top right corner.

A3 CFDIwt Coles A	AS Dist Color Color Zone Surger	A9 Dr Pepper
	Dispenser Locko	ut 🛞
	A	
Until I UnLock		disabled
Lock Until		05:00 AM (0
	Lock Dispenser	

There are two ways the dispenser can be locked:

- Manual setting: Slide the 'Until I Unlock' toggle switch to enable the manual unlock feature. Once enabled, the manager must enter the passcode to unlock.
- Time setting: Tap the button next to 'Lock Until' and set a time for the dispenser to unlock automatically when 'Until I Unlock' is disabled.



Once the dispenser is locked, you may unlock the user interface by using the manager passcode (2653). COCA-COLA FREESTYLE® 9100 | OPERATIONS

Calorie counter display

 $(\mathbf{1})$

How to enable the calorie counter display feature

To comply with the FDA menu-labeling regulations for chain establishments with 20 or more outlets, calorie counter must be accessible.

Entra			Zers Bager	la la ali	
Enter	ass	wor		®	
	1	2	3		
	4	5	6		
	7	8	9		
		0	٩		
		unlock			

Access crew dashboard. Tap login, in the header, and type the manager passcode 2653.

		XL						Help C		
1	2	3	4	6	6	7	8	9	0	
	9 1	v	ε	R	r	Y 1			-	
	A	8	D		0	н	J	к	L	
	z	×	c	v	8	N	м			
				Space			En	ter		

TIP: Create custom names and sizes by tapping on the drink name or portion size to adjust. Then click exit to return to the consumer interface.

Regions Dispenser Profile	Service Mode Apps Advanced
Service Mode	547
caloric display	
caloric display	dualitied (
screen transitions	
Attract	1 min 1 after Home is idle enabled
Home	8 sec 8 after p
"Are you still there?"	13 bec 8 train
ADA Home	30 sec 8 after s
ADA "Are you still there?"	30 sec 1 inc

Select settings and then choose Service Mode in the secondary navigation.

Service I	Aode	self
caloric disp	lay	_
caloric d	isplay	enabled
к	portion alze B oz F	enabled
	portion size 10 oz 8	enabled
м	portion size 12 oz 0	enabled
	portion size 20 ez I	enabled
XL		disabled (

Slide caloric display toggle to enabled to activate. Slide toggle icons to create a portion size. Green/right is enabled; Gray/left is disabled.

NOTE: The initial setting for the caloric display feature will be disabled.

Using & pairing with myCoke mobile app

myCoke Mobile App

Enables crew members to monitor dispenser ingredients via their smart devices, with no disruption to dispenser function. It helps crews efficiently maintain the dispenser by notifying them of required cartridge change-outs & cleaning tasks.

My Equipment

Shows the status of all machines in a particular outlet.

Ingredient Status Gauges

Highlights important information such as sold-out product, prime needed, and time remaining.

Cleaning Check Lists


Syncs status of cleaning and maintenance tasks between crew members.

About

Provides specific and detailed information for each dispenser.

Training

Creates easy access for crew to platform-specific training materials and troubleshooting guides on Crew Connect.




COCA-COLA FREESTYLE® 9100 | OPERATIONS

(2)

(4


Using & pairing with myCoke mobile app



to allow camera access and notifications.

Replacing cartridges

Replacing ingredient cartridges starts with knowing when a cartridge is empty or unavailable.



shows that the Sprite ingredient is empty. As a

result, the brand button is grayed out and will say "Not Available" when selected.

Sprite

1 hour

2%


remaining

Enjoy By MM/DD/YY

 $(\mathbf{2})$ View the amount of ingredient remaining within each cartridge by accessing the dashboard.

> Reference the level indicator next to the brand.

NOTE: Time remaining is an estimate based on historical consumption data. This feature may take up to three weeks after install.




(4) Separate the empty ingredient cartridge from the plastic tray and recycle the outer paperboard box.

 $(\mathbf{3})$ Remove the


Then clean tray with dish soap,

followed by approved sanitizer solution (Kay-5 Sanitizer®).



G 🔊







5 Using the cartridge slot cleaning

tool (part #149324 and #149325).

(6) Open new cartridge using perforated cartridge opening flap. CAUTION:

DO NOT use a sharp object to open.








9 Ensure the inaredient


(8) Place ingredient cartridge into plastic tray and ensure plastic fitment from cartridge pouch aligns with trav.



(10) Remove foil safety seal prior to inserting into the dispenser.



© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 9100 User Guide | V6 230123



Always replace any missing or damaged plastic trays immediately to prevent dispensing issues. Plastic trays can be ordered by calling 1-800-241-COKE (2655). In Canada, call 1-800-318-COKE (2655)

Replacing HFCS (high fructose corn syrup)

When to replace HFCS

There are several ways to determine if the HFCS BIB (bag-in-box) needs to be replaced.

Pour screen

All sweetened beverage buttons will be graved out.

Ingredient summary page

The HFCS BIB square will turn red and feature the message "HFCS Sold out."

Resetting HFCS

Once the HFCS new HFCS box is installed, press the iold out red HFCS box to reset, and the prime function will automatically follow.


Replacing HFCS and cleaning connector








NOTE: Always check product is within the Enjoy Bv Date.











Wait two minutes and repeat with clean sanitizer, then air dry.



(6) Attach the connector to the fitment and turn clockwise to tiahten.

(#149326)









Replacing NNS (non-nutritive sweetener)

COCA-COLA FREESTYLE® 9100 | PRODUCT REPLACEMENT

When to replace NNS

There are several ways to determine if the NNS BIB (bag-in-box) needs to be replaced.

Pour screen

All low/no-calorie beverage buttons will be graved out.

Ingredient summary page

The NNS square will turn red and feature the message "NNS Sold out."

Replacing NNS





NNS package and follow instructions for cleaning the NNS compartment and connector

> See page 26 for cleaning instructions.

3 Remove cap [/] from the new NNS package.


Place box in the compartment with arrows on the package facing up.

NOTE: Always check product is



NNS

Sold out



COCA-COLA FREESTYLE® 9100 | MAINTENANCE

Helpful cleaning tips

Coca-Cola recommends Kay-5° Sanitizer, or a comparable food-grade chlorine sanitizer.

If using Kay-5 Sanitizer, add 1oz (28,4g) packet of Kay-5 Sanitizer to 21/2-gallons (9.5L) of fresh, warm water in a clean bucket.



When using a chlorinated detergent other than Kay-5 Sanitizer, follow the instructions to produce a 100 ppm chlorine sanitizer solution.


Kay-5 Sanitizer, cleaning brush and replacement nozzle can be ordered by calling 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653)



COCA-COLA FREESTYLE® 9100 | MAINTENANCE

Cleaning nozzle, injector ring, and ice chute

Cleaning nozzle and injector ring



Allow to air drv.

Cleaning ice chute


 $(\mathbf{4})$ Scrub ring area including holes with pointed end of nozzle brush dipped



- $(\mathbf{5})$ Wipe ring with clean cloth and sanitizer until it comes away clean.
 - Wait two minutes.
 - Repeat scrubbing and wiping ring with clean sanitizer.



sanitizer down the dispenser drain



(2) Using the ice chute brush and approved sanitizer solution, clean the inside of the chute.





 (\mathbf{J}) Wait two minutes to allow to air dry, then repeat step 2 with fresh sanitizer solution.


 $(\mathbf{4})$ Wipe the outside of the ice chute tip using a clean cloth and fresh sanitizer solution.

Allow to air dry before resuming normal operation.


Cleaning ice bin

COCA-COLA FREESTYLE® 9100 | MAINTENANCE

Cleaning drain and cup rest









Pour remaining sanitizer solution slowly down drain.

Ensure the drain empties properly.






(4) Replace the spider drain plate and cup rest.




Cleaning the NNS compartment and connector


This cleaning task should be completed every time a box of NNS is changed and whenever you notice "white" crystals forming on the NNS connector.



COCA-COLA FREESTYLE® 9100 | MAINTENANCE


Cleaning exterior surfaces





26

Crew should frequently clean areas that accumulate drips, such as the







Cartridge maintenance

SmartPAKTM (paperboard) cartridges are lightweight, recyclable, and designed to optimize backroom storage space.

Inventory and quick replacements

- Be prepared during rush periods! Place fast-moving ingredient cartridges in extra trays and stage near dispenser for fast change outs.
- Use your oldest ingredient cartridges on hand first, i.e. "First-in, First-out."
- Alwavs ensure ingredient cartridges are organized by "Enjoy By Date" to effectively manage inventory.

Push-click trays

The Coca-Cola Freestyle 9100 uses the black plastic, push-click cartridge trays. The trays are designed to hold a single or double ingredient cartridge.

Storage conditions

Avoid storing cartridges and plastic trays near any heat source, standing water, or cleaning solutions.

Cleaning trays

Push-click cartridge trays should be 'hand washed' before insertion of a cartridge. **NEVER PLACE IN A DISHWASHER.** Placing trays in a dishwasher may warp the trays over time. Use dish soap, followed by Kay-5 Sanitizer® or approved equivalent and allow to air dry.


1 All and a start

Small parts

Customers may order up to \$25 worth of the following small parts per location.*

To request a small parts order, call the support team at 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653). More information can be found at crewconnect.coca-cola.com.






Nozzle Tip #144700

Single Cartridge Tray #160860

#1145555

Double Cartridge Tray #160861







#149326

*NOTE: Shipping requests other than standard ground transportation may be charged to your outlet.

CREW CONNECT

We are committed to maximizing the operational and business performance of your Coca-Cola Freestyle[®] by providing your crew with the support they need.

Premium Support Solutions

TRAINING

Training resources to keep your crew in-the-know, from first installation, through new hires, to new upgrades in equipment or processes.

- » Live Crew Onboarding
- » Crew Connect
- » Crew Training Reference Guide
- » Troubleshooting Guides

TOOLS

Our materials and support infrastructure make maintenance and cleaning easier - and keep your dispensers running smoothly.

- » Small Parts **1-800-241-COKE** (2653) In Canada, call **1-800-318-COKE** (2653)
- » QR Video Decals
- » Crew Reminders & Checklists
- » On-Dispenser Instructions
- » myCoke app

SERVICE

We are constantly innovating to better serve your operational and business needs with 24 hours 7 days a week support at **1-800-241-COKE** (2653) and turnkey technological solutions. In Canada, call **1-800-318-COKE** (2653).

- » MyCokeTech
- » On-Site Service
- » Remote Software Diagnostics & Analytics

To find out what **Coca-Cola Freestyle Crew Connect** can do for your business, contact your Coca-Cola Sales Representative.



Oi

