CarCola freestyle 8100 User Guide



COCA-COLA FREESTYLE® 8100

This guide provides general tips and ۲ proper maintenance procedures for your Coca-Cola Freestyle® 8100 dispenser.

COCA-COLA FREESTYLE® 8100

Contents

EQUIPMENT)
External compo	onents
Internal and ba	ckroom components

OPERATIONS

Understanding the user interface
Filling the ice bin
Pouring a drink
Accessing the ingredient summary and crew dashboard
Understanding the ingredient summary
Understanding the crew dashboard
Cartridge prime procedure

PRODUCT REPLACEMENT

Replace cartridge	
Replacing HFCS sweetener	
Replacing NNS sweetener	



. 4 5

•	•	•	•	. 6	
				. 7	
				. 8	
				10	
	•		•	. 11	
	•		•	12	
				13	

				14	
•	•			16	
•	•	•	•	18	

MAINTENANCE
Resetting the smart pour portion control
Helpful cleaning tips
Cleaning nozzles22
Clean ring area in nozzle tray23
Cleaning ice bin24
Cleaning drain and cup rest25
Cleaning the NNS compartment and connector26
Cleaning exterior surfaces
Cartridge maintenance28

RESOURCES


Small parts	29
Crew Connect	30

For crew training videos, visit crewconnect.coca-cola.com



COCA-COLA FREESTYLE® 8100 | EQUIPMENT

External components




- B Touch screen
- C Backsplash
- Ice bin lid
- E Lower door
- F Nozzle and injector ring
- G Water nozzle assembly


H Water nozzle

۲

- Diffuser
- J Cup rest
- K Scale cup rest
- L Drain
- M Drip tray
- N Drip tray drain strainer



COCA-COLA FREESTYLE® 8100 | EQUIPMENT Internal and backroom components



© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110



Understanding the user interface

A Primary brands

When a primary brand is selected.

B Empty or unavailable brands

Grayed-out brand buttons covered with a red X indicates the brand is out and unavailable for dispensing.

POS (Point-of-Sale)

Pressing the POS Button \cong opens the POS screen. This feature is optional.

D Cup scale

When there is no cup on the cup scale, pressing the Cup Scale Button 🖁 opens the Scale Calibration Screen. The button displays the current weight on the cup scale.

Summary

Pressing the Summary Button IIII opens the Ingredient Summary screen.

Specialty drinks


Specialty drinks are beverage flavors created for special promotions or unique to particular outlets.

G Previous pour

Features the primary brand most recently dispensed. Pressing this Previous Pour Button () will populate the brand flavors with those available for the primary brand indicated.

H Brand flavors

Flavors available for the selected primary brand. The selected flavor is indicated by an outline around the button.



Manual pour button

Pressing the Manual Pour Button > will begin dispensing beverage. Pressing the button once will start the pour and pressing the button a second time will stop the pour.

Smart pour portion cup choices

Displays cup sizes available for dispensing. Pressing any of the cup sizes after the primary brand and brand flavors are selected will auto-fill the cup.


Water dispense button

When this button is selected, water will dispense from water nozzle located to the right of the primary dispensing nozzle.

COCA-COLA FREESTYLE® 8100 | OPERATIONS Filling the ice bin

How to check and fill the ice bin

Maintaining the proper ice level is critical to ensuring quests receive a quality beverage. Check to ensure ice is at least ¹/₃ full at all times. Fill the ice bin by following these steps.




Fill a clean bucket with ice and slide open ice bin lid.


Store bought or "bagged ice" should NEVER be used as it may seriously damage the Coca-Cola Freestyle[®] 8100 dispenser ice bin

© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110





Dump the ice in the ice bin and fill until full (approximately 2" from the top). Do NOT overfill.



Close ice bin lid.

NOTE: Always keep the ice bin lid closed when not in use. This will reduce ice melting and prevent objects from falling into the ice bin.

COCA-COLA FREESTYLE® 8100 | OPERATIONS

1/3 full with ice

 $\hat{}$

W

Pouring a drink

• Open ice bin lid and fill

cup up 1/3 of the way with

ice and close ice bin lid.

• Place filled cup on scale

(1) Add ice

cup rest.

.....

(2) Select primary brand Choose primary beverage brand by pressing the desired Brand Button.




 $\overline{(\mathbf{3})}$ Select brand flavor Select brand flavor by pressing Flavor Button.

 $(\kappa)(s)(m)(l)(xl)$

$(\mathbf{4})$ Select a cup size Select Cup Size Button to start filling the cup using auto-fill smart pouring.

a (Califa) (Califa) (Califa) K S M



Previous pour

Features the primary brand most recently dispensed. Pressing this Previous Pour Button \mathbb{Q} will populate the brand flavors with those available for the primary brand indicated.

COCA-COLA FREESTYLE® 8100 | OPERATIONS



 \triangleright

In addition to smart pour selections, cups can be filled manually. Press the Manual Pour Button > once to start the pour. Press the button a second time to stop the pour.



۲




Manual pour

Pour water

Place cup on the water cup rest. Press the Water Button once to start the pour, press it a second time to stop the pour.





Accessing the ingredient summary and crew dashboard



From the pour screen press the

of the screen. This will open the

The Ingredient Summary screen

pour screen by opening the upper

can also be accessed from the

Ingredient Summary screen.

or lower dispenser door.

Summary Button III in the top right

(2) Access crew dashboard Ingredient Summary Action Require 13% Char Prime All Back to Pour Screen

Dashboard Notifications About 11 Sprine Part 1, Sprine Part 2, parts disper kin 100 miles 4, 54 10 miles 4, 54 10 miles 4, 54 10 miles 4, 54 10 miles 4, 55 10 Prime All

From the Ingredient Summary screen - press the Details Button 📖 to open instructions.

(3) Return to pour screen

Crew dashboard

Return to the pour screen, press the Exit Button at the top right and continue to follow the on screen

COCA-COLA FREESTYLE® 8100 | OPERATIONS

A High Priority

Items requiring immediate attention to resume function. Reach out to the support team for assistance at 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653).

B Action Required

Items requiring action:

- Change the cartridge if the ingredient is shown in a red sold-out status.
- Select the Prime All Button to prime the lines for the orange prime required gauges.

C Low levels

Highlights ingredients (less than 20%) which are running low and will need to be replaced soon.

D Details

Use to access the crew dashboard.

Back to Pour Screen (Close)

To return to the pour screen, select Close 🛞 or the Back to Pour Screen Button.

Remember, the lower door must be closed to get back to pour screen.

Ingredient summary

the Crew Dashboard.

If the Ingredient Summary screen or crew dashboard has not been accessed within the past 24 hours, a cleaning instructions screen will appear.



Pour screen

()



Understanding the ingredient summary

											(D)	
					I	Ingredi	ent s	Sumn	nary		Details	Close
(A		High Pric	ority									
		S16 Cherry, NA Ingredient in wrong slot, move to S14										
(e		Action R	equired									
		S13 Raspberry, NA Prime required	S21 Lime, NA Sold Out	S3 MM Lemonade A: NA Clean nozzle and prime								
Ġ	J	Low Leve	els									
9		A3 DietCoke A, NA	S15 Peach, NA									
		13%	<1 hour remaining 0%		(Prime All		Back to Pour	F Screen			

COCA-COLA FREESTYLE® 8100 | OPERATIONS

Understanding the crew dashboard

Dashboard

Sprite Part 2

7 days

S14 Cherry, NA

4 days

42%

Sprite Part 1,

8 days remaining

76%

A1 Coke A, NA, US

Notifications About

5 days

When crew members require a complete view of the status of all inaredients, the crew dashboard screen can be accessed.

Bold alerts

Review items requiring attention to resume ingredient function, such as prime or purge.

Contact the support team if you need assistance at 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653).

B Fuel gauges

Color-coded gauges displaying the remaining product percentage and Enjoy By Date of each cartridge improve cartridge change-out management for crew members and reduce product waste.

The percentage remaining and time before changing the product cartridge may vary significantly. For example, a flavor cartridge with 6% may have several days remaining, while a heavily used product cartridge, like Coca-Cola, may last only a few hours with 6%.

C Time remaining

57 Mello Vello A NA

5 days

0%

Prime All

Carb Agitator Scale

4 days

A time remaining feature provides an accurate reading when each cartridge will likely run out. This new feature is calculated using the dispenser's consumption activity and daypart data to deliver a dynamic and precise reading throughout the day.

S9 S10 Hig Solution CC HiC, NA

95%

9 days remaining

89%

9 days

1 hour

S11 S12 Powerade, US Fruit Punch, NA

5 days remaining

3 days

36%

9 days

2 days

S12

5 days

89%

S22

Vanilla, NA

<1 hour

Sremaining

Enjoy By MM/DD/YY

A

0%

remaining


Enjoy By MM/DD/YY

Fruit Punch, NA

COCA-COLA FREESTYLE® 8100 | OPERATIONS Cartridge prime procedure

Priming a product cartridge simply removes any trapped air in the line and ensures guests receive a consistent, quality beverage.







(1) Confirm the cartridge has been inserted into the correct slot and press Prime All at the bottom of the screen.

Ingredient Summary	III.	(X) Comm
iority		
Required		
Non no second de la constance		
vels		
STE Pauly M		
41 heart Intering		
Prime AD Reak to Poor Roman		
Prime All		

(2) When priming is complete, press Close \otimes in the top right of the screen. Follow the prompts on the pop-up to continue to the pour screen.

ligh Priority	Ingredient Summary	
ction Required		
ow Levels		
43 815		
ow Levels		

NOTE: Only press the Prime All Button **ONCE!** Pressing it more than once will needlessly repeat the prime process.

COCA-COLA FREESTYLE® 8100 | PRODUCT REPLACEMENT

Replacing cartridges

Replacing product cartridges starts with knowing when a cartridge is empty or unavailable.

(1) The screenshot shows that the Sprite ingredient is empty. As a result, the flavor icon is grayed out with a red \times and will say "Not Available" when


selected.

۲

 \bigcirc View the amount of S5 product remaining Sprite within each cartridge by accessing the dashboard. 1 hour remaining Reference the level 2% indicator next to the brand. Enjoy By MM/DD/YY


NOTE: Time remaining is an estimate based on historical consumption data. This feature may take up to three weeks after install.

For best practices regarding cartridge maintenance see page 28.



© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110

COCA-COLA FREESTYLE® 8100 | PRODUCT REPLACEMENT





Always replace any missing or damaged plastic trays immediately to prevent dispensing issues. Plastic trays can be ordered by calling 1-800-241-COKE (2655). In Canada, call 1-800-318-COKE (2655).



COCA-COLA FREESTYLE® 8100 | PRODUCT REPLACEMENT

Replacing HFCS (high fructose corn syrup)

When to replace HFCS

There are several ways to determine if the HFCS BIB (bag-in-box) needs to be replaced.


1. Pour screen

All sweetened beverage buttons will be grayed and covered with a red X.



2. Ingredient summary page

The HFCS BIB square will turn red and feature the message "HFCS Sold out."



Replacing HFCS and cleaning connector

Double check to see how much product is left by lifting the box.

(4)

 (\mathbf{A})



Use a cloth to catch any spills, and turn connector counterclockwise to loosen.




3 Remove connector ¹ and replace with new HFCS sweetener BIB **NOTE:** Always check


product is within the Enjoy By Date.

T NFCS 65% MINORARE STREETENER

۲







CAUTION: DO NOT use a sharp object 🔿 to open.



6 Attach the connector to the fitment and turn clockwise to tighten.





Once the new HFCS box is installed, press the red HFCS box to reset



and the prime function will automatically follow.



COCA-COLA FREESTYLE® 8100 | PRODUCT REPLACEMENT

Replacing NNS (non-nutritive sweetener)

When to replace NNS

There are several ways to determine if the NNS BIB (bag-in-box) needs to be replaced.


1. Pour screen

All low/no calorie beverage buttons will be grayed and covered with a red \times .




2. NNS status light

Inside the lower door, the NNS status light will turn red indicating the NNS needs to be replaced.




3. Ingredient summary page

The NNS square will turn red and feature the message "Sold out".



Replacing NNS



COCA-COLA FREESTYLE® 8100 | PRODUCT REPLACEMENT

© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110

(4) Remove cap from the new NNS package.

Place box in the compartment with arrows on the package facing up.

NOTE: Always check product is within the Enjoy By Date.



(5) Reattach the NNS connector then move the lever to secure.


> Lift up front door of NNS compartment to close.



6 Close the lower door when finished.

Then press the red box on the dashboard to reset the NNS.

NOTE: Always dispense one diet drink to ensure proper operation of dispenser.





Resetting the smart pour portion control


Smart pour technology dispenses the perfect pour by weighing the cup and its contents and calculating the amount of beverage to be dispensed.

At the time of installation, the smart pour portion control will be calibrated, but over time a reset may become necessary.

Reset cup scale

If the dispenser is not pouring beverages to the right level, the cup scale may need to be reset. Before resetting the cup scale, ensure that the scale cup rest is clean and properly seated in place.

See page 25 for cleaning instructions.



COCA-COLA FREESTYLE® 8100 | MAINTENANCE Helpful cleaning tips

Coca-Cola recommends Kay-5° Sanitizer, or a comparable food-grade chlorine sanitizer.

If using Kay-5 Sanitizer, add 1oz. (28.4g) packet of Kay-5 Sanitizer to 21/2-gallons (9.5L) of fresh warm water in a clean bucket.



When using a chlorinated detergent other than Kay-5 Sanitizer, follow the instructions to produce a 100 ppm chlorine sanitizer solution.


Kay-5 Sanitizer, cleaning brush and replacement nozzle can be ordered by calling 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653).

© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110

DO NOT place items heavier than 25lbs (11.3kg) on cup scale.








COCA-COLA FREESTYLE® 8100 | MAINTENANCE Cleaning nozzles

۲





COCA-COLA FREESTYLE® 8100 | MAINTENANCE

(4)

A

Clean ring area in nozzle tray






© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110



COCA-COLA FREESTYLE® 8100 | MAINTENANCE Cleaning ice bin



© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110


© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110

COCA-COLA FREESTYLE® 8100 | MAINTENANCE

۲




Cleaning drain and cup rest



3 Use the drain cleaning brush (small part #144925) to scrub the dispenser drain.


Pour remaining sanitizer solution slowly down drain.

Ensure the drain empties properly.






A Replace the drain strainer, cup rest and scale cup rest.



COCA-COLA FREESTYLE® 8100 | MAINTENANCE

Cleaning the NNS compartment and connector

This cleaning task should be completed every time a box of NNS is changed and whenever you notice "white" crystals forming on the NNS connector.



COCA-COLA FREESTYLE® 8100 | MAINTENANCE **Cleaning exterior surfaces**








© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110



Crew should frequently clean areas that accumulate drips such as backsplash and edge of ice bin.

(3) Wipe interior of upper and lower doors as needed.





COCA-COLA FREESTYLE® 8100 | MAINTENANCE

Cartridge maintenance

SmartPAK[™] (paperboard) cartridges are lightweight, recyclable, and designed to optimize backroom storage space.

Inventory and guick replacements

- Be prepared during rush periods! Place fast moving product cartridges in extra trays and stage near dispenser for fast change outs.
- Use your oldest product cartridges on hand first, i.e. "First-in, First-out."
- Always ensure product cartridges are organized by "Enjoy By Date" to effectively manage inventory.

Push-click trays


The Coca-Cola Freestyle[®] 8100 uses the black plastic, push-click cartridge trays. The trays are designed to hold a single or double product cartridge.

Storage conditions

Avoid storing cartridges and plastic trays near any heat source, standing water, or cleaning solutions.

Cleaning trays

Push-click cartridge trays should be 'hand washed' before cartridge insertion of a cartridge. NEVER PLACE IN A DISHWASHER. Placing trays in a dishwasher may warp the trays over time. Use dish soap, followed by Kay-5 Sanitizer® or approved equivalent and allow to air dry.



© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110

COCA-COLA FREESTYLE® 8100 | RESOURCES Small parts

Customers may order up to \$25 worth of the following small parts per location.*

To request a small parts order, call the support team at 1-800-241-COKE (2653). In Canada, call 1-800-318-COKE (2653). More information can be found at crewconnect.coca-cola.com.






Nozzle Tip #144700

XEEP OUT OF REACH OF CHILDREN CAUTION FER INSTITUTIONAL USE DALY

Water Nozzle Assembly #1145554



J

© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110

(4)



*NOTE: Shipping requests other than standard ground transportation may be charged to your outlet.

COCA-COLA FREESTYLE® 8100 | RESOURCES

CREW CONNECT

We are committed to maximizing the operational and business performance of your Coca-Cola Freestyle[®] by providing your crew with the support they need.

Premium Support Solutions

TRAINING

Training resources to keep your crew in-the-know, from first installation, through new hires, to new upgrades in equipment or processes.

» Live Crew Onboarding

» Crew Connect

» Crew Training Reference Guide

TOOLS

Our materials and support infrastructure make maintenance and cleaning easier - and keep your dispensers running smoothly.

» Small Parts 1-800-241-COKE (2653) In Canada, call 1-800-318-COKE (2653)

» QR Video Decals

- » Crew Reminders & Checklists
- » On-Dispenser Instructions

SERVICE

We are constantly innovating to better serve your operational and business needs with 24 hours 7 days a week support at **1-800-241-COKE** (2653) and turnkey technological solutions. In Canada, call 1-800-318-COKE (2653).

» MyCokeTech

» On-Site Service

» Remote Software **Diagnostics & Analytics**

To find out what Coca-Cola Freestyle Crew Connect can do for 🧭 your business, contact your Coca-Cola Sales Representative.

© 2023 The Coca-Cola Company | Confidential information of The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | V2 231110



 (\mathbf{D})

 $(\mathbf{1})$







© 2023 The Coca-Cola Company | Coca-Cola Freestyle® 8100 User Guide | Confidential information of The Coca-Cola Company | V2 231110