


Cleaning Nozzle and Injector Ring


To keep your dispenser running smoothly, crew members should pay special attention to cleaning the nozzle and injector ring, avoiding build up from splashing, dust, and other residue.

DAILY nozzle and injector ring cleaning:

- ① Using a clean cloth, twist the nozzle counter clockwise and pull down to remove.




- ② Scrub nozzle with blunt end of nozzle brush and soap. Rinse with warm water. Allow to air dry.




- ③ Submerge nozzle in sanitizer for two minutes.

Agitate to remove air pockets.



- ④ Scrub ring area including holes with pointed end of nozzle brush dipped in sanitizer.




Scrub inner injector rings with wire-handled brush dipped in sanitizer.

- ⑤ Wipe ring with clean cloth and sanitizer until it comes away clean.

Wait two minutes. Repeat scrubbing and wiping ring with clean sanitizer.

- ⑥ Re-insert nozzle by pushing upward and rotating clockwise.


Pour remaining sanitizer down the dispenser drain. Allow to air dry.




Order small parts by calling
1-800-241-COKE




Kay-5 Sanitizer®
#24041



Microfiber Cloth
#127723



Wire Handled
Nozzle Brush
#1145555



Nozzle & Injector
Ring Brush
#143257

For more information and training resources on Coca-Cola Freestyle, please visit on crewconnect.coca-cola.com