



TROUBLESHOOTING


QUICK CHECKLIST BEFORE YOU CALL

Save Time & Money

1 Out of syrup

FBD

PRODUCT OUT LIGHTS ARE FLASHING
NOT READY ANY SINGLE BARREL



Replace empty syrup BIB container

Cornelius




AFFECTED BARREL ONLY

2 Out of CO₂ or water

FBD

PRODUCT OUT LIGHTS ARE FLASHING
NOT READY ANY SINGLE BARREL



Replace empty CO₂ / check the water supply

Cornelius



3 Unit is defrosting

FBD

PRODUCT OUT LIGHTS ARE FLASHING
NOT READY ANY SINGLE BARREL



FBD

- Select barrel then once window comes up select **OFF**
- Select barrel again then select **ON**

Cornelius

Wait until unit completes defrost and freezes product
DO NOT SERVE light will turn off

Cornelius



4 Unit in 1st freeze after defrost

FBD

PRODUCT OUT LIGHTS ARE FLASHING
NOT READY ANY SINGLE BARREL



FBD

Wait until unit completes first freeze down cycle

Cornelius

Wait until product is ready to serve
DO NOT SERVE light will turn off


Cornelius



5 Unit is in "sleep" mode

FBD

PRODUCT OUT LIGHTS ARE FLASHING
NOT READY ANY SINGLE BARREL





Select barrel then select **ON**

6 Barrel is turned off

FBD


PRODUCT OUT LIGHTS ARE FLASHING
NOT READY ANY SINGLE BARREL



Select barrel then select **ON**

7 No lights / unit not running

NO LIGHTS AND THE UNIT IS NOT RUNNING



Plug in or reset circuit breakers

NEED ASSISTANCE? Call ICEE 800-423-3872 or email servicecall@icee.com

