




Coca-Cola  
freestyle

**One brand or  
flavor is out**

## TROUBLESHOOTING GUIDE


HERE IS WHAT TO DO!



**Does an ingredient cartridge  
show sold out?**

**IF YES**, replace the empty  
ingredient cartridge.


STILL HAVING TROUBLE, TRY THESE STEPS



If the ingredient cartridge does not show  
sold out, remove and reinsert the partially  
used cartridge.



Clean the nozzle assembly  
and injector ring.



Prime the ingredient cartridge.

STILL NOT RESOLVED, CONTACT US

Visit the web portal at

**myCoke.com/ESPortal**

Or contact a dedicated  
Coca-Cola Service Technician at

IN THE U.S.

**1 (800) 241-COKE (2653)**

IN CANADA

**1 (800) 318-COKE (2653)**

Coca-Cola  
freestyle