



TROUBLESHOOTING


QUICK CHECKLIST BEFORE YOU CALL

Save Time & Money

1 Nothing dispenses



Check if dispenser is plugged in



Press electrical reset button




Check the breaker box


2 No water on valve/blowing air




Check if water is turned on



Press electrical reset button




Check outlet power or reset circuit breaker



Replace water filters if needed


3 No syrup dispensing from valve



Change/fill CO₂ tank if less than 105 psi



Confirm BIB is not empty



Confirm BIB connector is firmly attached

4 Drinks have an off-taste



Check BIB "Enjoy By" date




Clean dispenser nozzle




Check if water filters are current and replace if necessary

5 Drinks are dispensing weak




Change/fill CO₂ tank if less than 105 psi



Check to ensure lines are not kinked

6 Product selection buttons are not sensitive enough




1 Unplug or turn key switch off



2 Clean product selection lens with slightly damp cloth



3 Completely dry lens with clean cloth



4 Plug in or turn key switch on

NEED ASSISTANCE? The myCoketech Team is here to help.
Go to myCoke.com/ESPortal or call/text 1-800-318-COKE (2653)

